


Power supply section

LVB10378-A1



To Power amplifier section
CN703

To System control section
CN201

To System control section
CN202

▲ Parts are safety assurance parts.
 When replacing those parts make
 sure to use the specified one.